

**Pushbutton sensor 4.70 Komfort, 4-gang for Gira One and KNX System 70, with start-up rocker**



| <b>Spezifikation</b>  | <b>Bestell-Nr.</b> | <b>VE</b> | <b>PS</b> | <b>EAN</b>    |
|---|--------------------|-----------|-----------|---------------|
|  | 5344 00            | 1/5       |           | 4010337128779 |