








## Deksel med dreieknapp for tidsbryter og persiennebryter el. -trykknapp



| Spesifikasjon   | Bestillings nr. | PE  | PS | EAN           |
|---|-----------------|-----|----|---------------|
|  kremhvit glans      | 0666 01         | 1/5 |    | 4010337666011 |
|  renhvit glans     | 0666 03         | 1/5 |    | 4010337666035 |
|  renhvit silkematt | 0666 27         | 1/5 |    | 4010337666271 |
|  antrasitt         | 0666 28         | 1/5 |    | 4010337666288 |
|  aluminiumsfarget  | 0666 26         | 1/5 |    | 4010337666264 |
|  svart matt        | 0666 005        | 1/5 |    | 4010337036586 |
|  grå matt          | 0666 015        | 1/5 |    | 4010337081401 |

### Merknader

- Denne bryterfronten er egnet for universalbruk, ettersom de medfølgende symbolskivene for persienne og tid kan skiftes.

## Leveringsomfang

- Inkludert symbolskiver for persienne ( $\Delta$ ,  $\nabla$ ) og tid (15 til 120 min eller 30 til 60 min).

---