








Deksel med dreieknapp for tidsbryter og persiennebryter el. -trykknapp



Spesifikasjon	Bestillings nr.	PE	PS	EAN
 kremhvit glans	0666 01	1/5		4010337666011
 renhvit glans	0666 03	1/5		4010337666035
 renhvit silkematt	0666 27	1/5		4010337666271
 antrasitt	0666 28	1/5		4010337666288
 aluminiumsfarget	0666 26	1/5		4010337666264
 svart matt	0666 005	1/5		4010337036586
 grå matt	0666 015	1/5		4010337081401

Merknader

- Denne bryterfronten er egnet for universalbruk, ettersom de medfølgende symbolskivene for persienne og tid kan skiftes.

Leveringsomfang

- Inkludert symbolskiver for persienne (Δ , ∇) og tid (15 til 120 min eller 30 til 60 min).
