








Deksel med dreieknapp for tidsbryter og persiennebryter el. -trykknapp



| Spesifikasjon | Bestillings nr. | PE | PS | EAN |
|---|-----------------|-----|----|---------------|
|  kremhvit glans | 0666 01 | 1/5 | | 4010337666011 |
|  renhvit glans | 0666 03 | 1/5 | | 4010337666035 |
|  renhvit silkematt | 0666 27 | 1/5 | | 4010337666271 |
|  antrasitt | 0666 28 | 1/5 | | 4010337666288 |
|  aluminiumsfarget | 0666 26 | 1/5 | | 4010337666264 |
|  svart matt | 0666 005 | 1/5 | | 4010337036586 |
|  grå matt | 0666 015 | 1/5 | | 4010337081401 |

Merknader

- Denne bryterfronten er egnet for universalbruk, ettersom de medfølgende symbolskivene for persienne og tid kan skiftes.

Leveringsomfang

- Inkludert symbolskiver for persienne (Δ , ∇) og tid (15 til 120 min eller 30 til 60 min).
