© Copyright by
Gira Giersiepen GmbH & Co. KG
All rights reserved

Rocker switch and button insert 10 A 250 V~



Specification	Order No.	Packing unit	PS	EAN
	0139 00	-	-	4010337022725

Features

- Rocker switch and button in which the left rocker is laid out as a switch and the right rocker is laid out as a push button.
- For switching and colour control of an LED orientation light.
- For controlling motion detectors manually.
- For activating dimmer auxiliary units.
- For controlling switched lighting.

Technical data

Installation depth:	32 mm
Connection cross section - For rigid and flexible conductors up to:	2.5 mm²
Rated output - LEDi/CFLi:	100 W

Notes

- Subject to availability.

Illustrations are similar and may deviate from originals.